

FIBERMATE Plus™ Frame Installation and Finishing

12186382 6/19

Install frame with Resolve® Sealant against the exterior side of the door. Door surface must be smooth and clean around the cut-out to ensure proper seal.

Frame Finishing Instructions

This frame is designed to be painted and/or stained. Use the same high quality exterior grade paint or stain as used to finish the entry door. Avoid paint overspray on sealant when finishing this frame.

Frame Surface Preparation

The frame should be free of any dust and debris. Wipe clean with mild detergent and water. The frame should be dry and acclimated to room temperature before applying paint. No other surface prep is necessary for finishing this frame.

NOTE: Do not apply adhesion promoters or primers to this frame.

Painting & Staining

PAINTING – Recommended for use with exterior latex paint. Apply thin coats, allowing paint to dry between coats, to achieve the desired coverage and finish.

STAINING – A 2-Step staining process is recommended for the most desirable level of adhesion. Step 1- apply an opaque base coat of paint to the frame, as described above. Step 2- apply the stain to the frame. Work stain into the graining with a sponge or cloth. Wipe off the excess stain for the desired finish. Follow manufacturer's instructions if different from above recommendation. Apply a compatible clear top coat to protect the finish.

Cleaning

Avoid contact with abrasive cleaners and solutions containing corrosive solvents or acid solutions.

Safety Glass

To view glass certification standards visit sgcc.org, or refer to the temper stamp on the glass.

Patent and Warranty

<https://www.odl.com/patents.htm>

<https://odl.com/downloads.htm#warranties>